

# Hitzer

Description and Part #	254	354	983	30-95	50-93	55FA	55-55UL	75-75C	82UL	82-82FA
<b>Blower Assembly</b>										
1C134H	1			1						
1C212		1			1					
1C465						1	1			
1C980H								1	1	1
1TF1012L			1							
1TF1012R			1							
<b>Glass</b>										
7GHLSD		1	1		1					
7GHSSD	1			1						
7GHDD		2	2							
<b>Grates</b>										
9254GH	2			1						
9354GH		1			2					
9354GXH		1								
975GH								2	2	2
9983GH			3			2	2			
<b>Firebrick</b>										
5B941	10	12	13	12	12	14	14	16	16	16
5FB134H								9	9	9
5FB29H			2							
<b>Gasket</b>										
6F12 (Feed Door)	7'	7'	7'	7'	7'	7'	7'	7'	7'	7'
6F34 (Ash Door)	7'	7'	7'	7'	7'	7'	7'	7'	7'	7'
<b>Spring Handles</b>										
2SH12 (Feed & Ash Door)	1	1	1	1	1					
2SH12 (Grate Shaker)	1	1		1	1					
2SH38212 (Damper)	1	1	1							