

# Atlanta Stove Parts

Application Chart														
Models														
Description and Part Number	<u>126, 26</u>	<u>124A</u>	<u>240A</u>	<u>2400</u>	<u>2401U</u>	<u>2410GU</u>	<u>524, 240DG, 340ADG</u>	<u>3400</u>	<u>524UA, 3401U</u>	<u>3418U</u>	<u>516U</u>	<u>624GU</u>	<u>624U</u>	<u>624UB</u>
Grates														
AT3900										1	1			
AT3901										1	1			
AT6487		2	2	2	2	2						2	2	2
AT6498							1	1	1					
AT6499							1	1	1					
AT6990	1													
Grate Rest														
AT3902										1	1			
AT6497							1	1	1					
Grate Support														
AT5574 (Wood)		6	6	6	6	6						6	6	6
Liners and Clamps														
AT1629 (Rear)		1	1		1	1	1					1	1	
AT1651 (Front)		1	1		1	1	1					1	1	
AT1737 (Rear)				1										1
AT1753 (Rear)								1	1					
AT3001 (Rear)										1	1			
AT6477 (Left Rear)		1	1		1	1						1	1	
AT6478 (Left Front)		1	1		1	1						1	1	
AT6479 (Right Rear)		1	1		1	1						1	1	
AT6480 (Right Front)		1	1		1	1						1	1	
AT1732 (Clamp)				4			5	5	5					4
AT6483 (Clamp)		4	4		4	4						4	4	
Ashpan														
AT93011										1	1			
AT90814		1	1	1	1	1	1	1	1			1	1	1
Firebrick														
5B941		10	10	10	10	10	13	13	13	13	13	10	10	10
Flue Collar														
AT6473		1	1	1	1	1	1	1	1	1	1	1	1	1
Handle														
AT6556				1	1	1		1	1	1	1	1	1	1