

US Stove

Description and Part #	W 2600	W2621	W 2921	W 3021	2627	W 2721	2821	C 2927	C 5027	2727	2827	20 FB
Grates												
US40076	2	2	2	2		2	2					
US40101					1			1		1	1	
US40043									1			1
Draw Grate												
US40044												1
Shaker												
US40045					1			1		1	1	1
US40214									1			
Grate Support												
US66080	2	2	2	2		2	2					
US40130										5		
US22536											2	
Firebrick												
5B941	10	10	10	10	10	10	9	5	12	10	10	
Brick Support												
US40046												1
Bracket												
US40210 (Rear)									1			
US40209 (Front)									1			
Firebrick Retainer												
US17350 (Rear)	2	2	2	2		2	1					
US40132					2			1		2	2	

US Stove - continued

Description and Part #	W 2600	W2621	W 2921	W 3021	2627	W 2721	2821	C 2927	C 5027	2727	2827	20 FB
Grate Frame												
US40102					1			1		1	1	
Optional Blower												
USF36	1	1	1	1	1	1	1	1	1	1	1	
Motor Only												
US80114	1	1	1	1	1	1	1	1	1	1	1	
Handles												
US40091FA		1	1	1	1	1	1	1		1	1	
US40091AA		1	1	1	1	1	1	1		1	1	
US89210FA									1			
US89210AA									1			
Ashpans												
US67444	1	1	1	1	1	1	1			1	1	
US67245												1
US68574								1				
Liners												
US22247 (Front)		3	1			1	1					
US17130 (Back)	1	1				1	1					
US17120 (Front)	1			1								
US40100 (Front & Back)					3			1		3	3	
US40220 (Front)									1			
US17150 (Back)	1	1										